

GRAFAX is an interactive graphics system developed by A.O. SMITH Corporation. It is a proprietary computer program designed for use with MSC/NASTRAN. Pre and post-processing of FEM (Finite Element Model) data can be done at any location through the use of a graphics or RJE terminal connected to a time sharing system. GRAFAX is also available to run on some mini-computers.

GRAFAX is a user oriented system designed to create, verify, and update FEM data and study the FEA output. It can produce a new model file or restart an existing model file with input and/or output data. There are eight main functions of GRAFAX. These and their roles are as follows, in alphabetical order:

- DIGIT - Creates FEM data by digitizing the geometry of a model from scaled drawings on a graphics tablet.
- EDIT - Generates new FEM data. Modifies and/or adds FEM data.
- GRAPH - Produces line graphs of displacements, constraint forces, element forces, element stresses, and applied loads generated by the FEA.
- PRINT - Produces listings of displacements, constraint forces, element forces, element stresses, and applied loads generated by the FEA.
- REPORT - Produces one page summary reports of maximum/minimum displacements, constraint forces, element forces, element stresses, and applied loads generated by the FEA.
- RUN - Creates, updates, and submits a FEA batch run deck.
- SECTION - Calculates beam cross section properties and adds FEM property cards to the file. After the FEA SECTION can calculate local collapse coefficients, or beam stresses at other than originally specified recovery points.
- VIEW - Draws pictures of the undeformed and/or deformed FEM. Produces CALCOMP plots.

When GRAFAX is executed at a graphics terminal the GRAFAX major functions menu will be displayed when the system is ready for a function to be entered. This major functions menu is shown in Figure 1.

AOS GRAFAX MAJOR FUNCTIONS MENU

PRE-PROCESSOR FUNCTIONS

DIGIT ---- DIGITIZE DATA FROM DRAWING
EDIT . ---- EDIT OR GENERATE DATA
SECTION---- CALCULATE BEAM PROPERTIES
VIEW ---- VIEW UNDEFORMED MODEL

POST-PROCESSOR FUNCTIONS

SECTION---- CALCULATE BEAM COLLAPSE COEFFICIENT
GRAPH ---- GRAPH FEA
PRINT ---- DISPLAY FEA
REPORT ---- SUMMARIZE FEA
VIEW ---- VIEW DEFORMED MODEL

SPECIAL FUNCTIONS

END ---- END SESSION
HELP ---- DISPLAY MAJOR FUNCTIONS MENU
RUN ---- CREATE, EDIT & SUBMIT A BATCH RUN DECK

Figure 1. GRAFAX Major Functions Menu.

This major functions menu shows each of the main functions and gives a brief description. It also shows which ones are used for pre and post-processing. There are also three special functions.

The special functions are normally used at any time before or after a FEA run has been made. The END function is used to end a GRAFAX work session. The HELP function is used to create a display of the major functions menu on the screen. The RUN function is used to prepare and submit a batch FEA run deck. It might also be used to modify an existing batch run deck and resubmit it.

The pre-processing functions are used before a FEA run is made. DIGIT is used to generate grid point and element connection data for a model by digitizing the geometry and connectivities from a drawing. The EDIT function is used to modify data generated using the DIGIT function, modify data that was already in the file, and add new data by entering the data via the terminal keyboard. The EDIT function also has data generating capabilities. The SECTION function is

used to calculate structural properties of thin-walled beam cross-sections and automatically fill out and add the FEM property data to the file. Data for this can be either digitized and/or entered via the terminal keyboard. The VIEW function is used to verify the geometry, element connections, and element properties of the model. Errors are often very obvious and once spotted, can be corrected by using the EDIT function. The VIEW function should always be used to verify the geometry of a model before a FEA run is made.

The post-processing functions are used after a FEA run is made. They should be used to study and evaluate the significance of a run, and eliminate the need for a standard printout.

The GRAPH function is used to prepare line graphs of the output that show range and magnitude of a parameter on the output for each grid point or element connection. From these line graphs the ranges and magnitudes can be seen at once and this can be used to determine the significance of the run and then to find critical areas of the model. The PRINT function is used to selectively generate the printout. The REPORT function is used to summarize the results of a type of output. It gives the magnitude of the minimum/maximum of each parameter in the output and the user grid point or element IDs at which they occurred. This can be used with the GRAPH function to pinpoint critical areas. The VIEW function is used to draw deformed or modal pictures of a model. This is very useful in understanding the behavior and significance of a model. The SECTION function is used to calculate local collapse coefficients and stress recovery data for thin-walled beam cross sections that have been created using this function.

A function is called by typing the function name at a terminal keyboard and pressing the RETURN key. Then, any one of the function's commands can be executed by typing in the command and again pressing the RETURN key. The RETURN key forwards the information to the computer and so should always be pressed after typing anything at the keyboard. A command that requires an end signal can be ended by pressing the RETURN key, thus entering a blank line. To end a digitizing command a R must be entered before pressing the return key. This also ends a function. After a command or function has ended, a prompt to enter a new command or function will always appear on the screen.

Figure 2 illustrates the process of using GRAFAX to generate a model, submit model to a FEA program, and examine the FEA output. The model can then be modified and rerun as needed.

GRAFAX INPUT FILES

The GRAFAX system uses the FEA input and output files. Each file has a unique name assigned by the user. When a GRAFAX work session begins, the system will prompt for a filename (if none was entered). The user must then enter a new or existing filename. The GRAFAX system then searches the user work library for files with the specified name and prints one of following four messages:

1. AN INPUT FILE CALLED XXXXXX IS BEING CREATED.

This message is printed when the entered filename was not found in the user work library. The filename will be created on the user work library with a data format, and used to store GRAFAX output for later use.

2. AN INPUT FILE CALLED XXXXXX IS BEING RESTARTED.

This message appears when the entered filename is found in the user work library with an output format. The data in this file is read into the GRAFAX system. The filename will also be used to create a data format file under that name on the user work library to store GRAFAX output for later use.

3. AN OUTPUT FILE CALLED XXXXXX IS BEING RESTARTED.

This message appears when the entered filename is found in the user work library with an output format. The data in this file is read into the GRAFAX system. The filename will also be used to create a data format file under that name on the user work library to store GRAFAX output for later use.

4. INPUT AND OUTPUT FILES CALLED XXXXXX ARE BEING RESTARTED.

This message is printed when the entered filename is found in the user work library with both data and output formats. The data in both files is read into the GRAFAX system. If FEM data exists on both files, the data from the output file is used. The data format file will then be reused to store GRAFAX output for later use.




Figure 2. Using the GRAFAX system for Finite Element Modeling.

The XXXXXX in the above messages represents the entered filename.

A GRAFAX input file may contain the complete, or part of a FEA run deck. This file always has a data format. Figure 3. shows the card image order of a typical run deck stored in the input file.

```
JOB CONTROL LANGUAGE CARD IMAGES
:
:
FEA CONTROL CARD IMAGES
:
:
FEM DATA CARD IMAGES
:
:
JOB CONTROL LANGUAGE CARD IMAGES
:
:
```

Figure 3. Order of Typical FEA Run Deck.

It is not necessary to have the Job Control and FEA control cards in the input file. But, when they are present, the following rules must be adhered to:

1. The first card must be a job card.
2. The following cards must be arranged as they would be given to the FEA program.

A GRAFAX post-processor input file may contain FEA output of FEM data, displacements, applied loads, constraint forces, element forces, and element stresses. This file always has an output format and is created during the FEA run if requested. TABLE 1 lists the GRAFAX identification number that is assigned to each type of FEA output. These identification numbers will appear in user messages if the type of FEA output requested is not in the user output file.

When each GRAFAX session ends, any FEM data and run deck cards are stored in a data format file of the filename given at the beginning of the session. This data file should be moved to the user's permanent library.

TABLE 1. GRAFAX IDENTIFICATION NUMBERS FOR FEA OUTPUT.

TYPE	DESCRIPTION
0	GRAFAX GENERAL PURPOSE PLOT DATA
1	GRID DISPLACEMENT DATA
2	GRID CONSTRAINT FORCE DATA
3	GRID APPLIED LOAD DATA
4	BAR ELEMENT FORCE DATA
5	TRIA ELEMENT FORCE DATA
6	QUAD ELEMENT FORCE DATA
7	BEAM ELEMENT FORCE DATA
8	BAR ELEMENT STRESS DATA
9	TRIA ELEMENT STRESS DATA
10	QUAD ELEMENT STRESS DATA
11	BEAM ELEMENT STRESS DATA
12	TRIAX6 ELEMENT CENTER STRESS DATA
13	TRIAX6 ELEMENT GRID STRESS DATA
14	PENTA ELEMENT CENTER STRESS DATA
15	PENTA ELEMENT GRID STRESS DATA
16	HEXA ELEMENT CENTER STRESS DATA
17	HEXA ELEMENT GRID STRESS DATA

The DIGIT function is used to create data card images by digitizing on a graphics tablet the geometry of a model from a scaled drawing(s). The drawing(s) must have two parallel views with X, Y, and Z axes that correspond to one of the orientation coordinate systems shown for the DIGIT ORIENT command.

The DIGIT function is useful as a pre-processing tool. It can be used to quickly calculate grid locations and generate grid data. Beam, tria and quad element connection data can also be generated. This data is generated using the generating parameter values specified in the KEYBOARD command. For each work session the generating parameters are reset to their default values. These generating parameters can be changed as often as needed by using the KEYBOARD command. They should be changed when the user desires to have a specific value for a parameter on the next generated data. These parameters might be the grid or element ID, property ID, beam orientation vector, and input/output coordinate systems. The generating parameters are changed by entering its identifying name and the new value. The grid and element ID's that are entered will always be incremented by their respective increments before the next one is generated.

The EDIT function is used to modify, add, and generate new FEM data card images. FEM card images are divided into three classes when a GRAFAX work session begins. The three classes are element connections, grid points, and miscellaneous. The element connection class consists of all element connection data. The grid point class consists of all grid data, and the miscellaneous class consists of everything else.

The basic editing commands available in the EDIT function are add, change, delete, insert and list. These basic commands can be used for all three classes of data. The first letter of an EDIT command refers to the basic command and the second letter refers to the class of data.

Line numbers are assigned to all card images. These line numbers are used with the EDIT commands to specify which card images are to be updated. EDIT commands and line number(s) can be entered at the same time.

EDIT also has a series of commands that are used to create and modify generating card images. These generating card images are then used as input for another EDIT command that generates new data card images. One, two, and three dimensional fields of grid, element connection and miscellaneous data card images can be automatically generated. Geometric progression can also be applied to these fields. Continuation card images can be automatically generated if more than one data card image is required. A card image may have two continuation card images.

EDIT is useful as a pre-processing tool in helping to quickly make changes to FEM data card images. It is an alternative to keypunching and traditional methods of changing a library data file. Edit can be used at any time to modify data card images. It is normally used after errors have been found or new data card images are to be added. FEM geometry, element connection, and element property errors are often very obvious when using the VIEW function. They can be corrected by using the EDIT function and then the VIEW function can be used to verify corrections. DIGIT errors can also be corrected by using the EDIT function.

EDIT also has a powerful data generation capability. One, two, and three dimensional fields of grid, connection, or miscellaneous data card images can be generated with only a few input data card images. These input data card images can then be modified and used again and again. Geometric progression can be applied to groups of data. This feature will be very useful when regular or semi-regular data patterns exist.

The GRAPH function is used to produce line graphs of FEA output. Graphs of applied loads, displacements, constraint forces, element forces, and element stresses can be made for any of the FEA subcases.

The horizontal axis of each graph represents internal grid point or element connection location identification numbers. Internal identification numbers are assigned to all grid point and element connections. Each grid point and element connection is numbered starting with one and increases in increments of one for each of their occurrences in the FEA output. These internal identification numbers will differ from the user assigned identification numbers if the user assigned identification numbers are not consecutive starting with one.

Internal identification numbers are used to make a one to one correspondence to the user assigned identification numbers and zoom-in on any area of a graph for more detailed results. They also can be used to examine the same output in the PRINT and REPORT functions.

Each of the GRAPH commands has an all feature. If all is entered on the prompt for subcase number then each subcase in the output file with the specified output will be automatically graphed and hard copied.

One, two or three different lines are used on the graphs. These different lines have specific meanings for each command. See the specific command for the meaning of the line(s).

After each graph is made a prompt for range to be graphed will appear. To zoom-in on the graph, enter the desired range. To end a command, enter a blank line by pressing the RETURN key.

REMARKS:

GRAPH is useful as a post-processing tool in helping quickly present an overall view of the output. The line graphs that can be generated will show the range and magnitude of parameters in the output. This step of finding the range and magnitude is very time consuming when only using the computer printout, and considering different loadings, and constraint conditions for a FEM.

With the available line graphs, ranges and magnitudes can be seen at once. This is very useful in determining the significance of the FEA or in finding critical areas. For element output, areas of tension, compression, and bending can be identified. This is useful in understanding the behavior of a FEM. These line graphs may be even more meaningful if the user considers the grid point and element numbering scheme at the time the model is being constructed.

The PRINT function is used to look at output generated by the FEA. Listings of applied loads, displacements, constraint forces, element forces, and element stresses can be produced for any of the FEA subcases. The listing format is similar to the FEA printout.

Internal identification numbers are assigned to all grid point and element connections. Each grid point and element connection is numbered starting with one and increases in increments of one for each of their occurrences in the FEA output. These internal identification numbers will differ from the user assigned identification numbers if the user assigned identification numbers are not consecutive starting with one.

Internal identification numbers are used to make a one to one correspondence to the user assigned identification number. They are also used to examine the same output in GRAPH and REPORT functions.

Each of the PRINT commands has an all feature. If all is entered on the prompt for internal range to be listed then all output for the specified subcase will be listed and hard copied automatically.

After each listing is made, a prompt for range to be listed will appear. Any one or range of internal identification numbers can be entered. To end a command enter a blank line by pressing the RETURN key.

PRINT is useful as a post-processing tool. It can selectively list all or any part of the FEA output for a subcase. This can be helpful for spot checking areas of the FEA output before or after an actual FEA printout is made. Hopefully, it can eliminate the printout if PRINT is used along with the GRAPH and REPORT functions to determine the significance of the FEA run.

The REPORT function is used to produce one page summary reports of output generated by the FEA. Reports of applied loads, displacements, constraint forces, element stresses can be made for any of the FEA subcases.

Internal identification numbers are assigned to all grid points and element connections. Each grid point and element connection is numbered starting with one and increases in increments of one for each of their occurrences in the FEA output. These internal identification numbers will differ from the user assigned identification numbers of the user assigned identification numbers are not consecutive starting with one.

Internal identification numbers are used to make a one to one correspondence to the user assigned identification numbers. They are also used to examine the same output in GRAPH and PRINT functions.

Each of the REPORT commands has an all feature. If all is entered on the prompt for subcase number then each subcase in the output file with the specified output will be automatically reported and hard copied.

Each report gives the maximum and minimum of important parameters in the specified output. The user assigned element or grid IDs where these extremes occur is also given.

After each report is made, a prompt for range to be reported will appear. Any range of internal identification numbers or all can be entered. A minimum range of two is required for a report. To end a command enter a blank line by pressing the RETURN key.

REPORT is useful as a post-processing tool in helping quickly present a summary of the FEA output. The reports that can be generated will show the range and magnitude of the minimum/maximum of important parameters in the output. They also will give the user element a grid location identification numbers where these extremes occur. These summary reports can be used effectively with the GRAPH and PRINT functions to identify precisely the extreme magnitudes and user location identification numbers on graphs and listings.

The RUN function is used to create and modify a FEA batch run deck. It is also used to submit the complete file for a batch run. The batch run deck contains all card images required for the FEA program except the basic FEM data. This deck should also contain all required JCL (Job Control Language) card images. Figure 4 show the card image order of a general FEA run deck. Figure 3 shows the card image order order of a complete FEA run deck.

```
JOB CONTROL LANGUAGE CARD IMAGES
:
FEA CONTROL CARD IMAGES
:
JOB CONTROL LANGUAGE CARD IMAGES
```

Figure 4. Order of general FEA Run Deck.

It should be noted that any FEM data is automatically inserted after the FEA control card images each time the message data saved appears and when a FEA batch run is submitted. When a file is restarted all FEM data is located in the EDIT function and all JCL and FEA control card images are located in the RUN function.

The basic editing commands available in the RUN function are add, change, delete, insert and list. Line numbers are assigned to all card images. These line numbers are used with the above commands to specify which card images are to be updated. Editing commands and line number(s) can be entered at the same time.

A default FEA run deck can be automatically added by using the ADD DEFAULT DECK command. These card images can then be modified to meet the users specific needs. The card images that are generated will vary depending on the FEA program name specified at the beginning of the GRAFAX work session and on the host computer system being used.

The SUBMIT command is used to submit the complete file for a batch FEA run. Another command called BATCH is used for typical library maintenance and data transfer (to and from mini-computer work stations) jobs.

RUN is useful as a pre-processing tool in helping quickly prepare, modify, and submit a FEA batch run. It is an alternative to keypunching and traditional methods of preparing and submitting a batch run. RUN can be used at any time to modify or create a batch run deck. This function is very unique because all necessary data for a FEM can be stored in one place(a library data file), and recalled at any time to be used again.

The SECTION function is used to create beam cross section data. Then, structural properties, local collapse coefficients and stress data can then be calculated from cross section data and FEA output.

There are two methods of preparing beam cross section data. The first is by using the DIGITIZE DATA command and its subcommands. With this method, section data is entered by digitizing on a graphics tablet the geometry of a cross section from a scaled drawing. The second method is to use the terminal keyboard to input the cross section data. The ADD, CHANGE, DELETE, and LIST commands can be used to input and modify section data card images. The RETRIEVE SECTION DATA command can also be used to reuse old section data.

There are four section input data cards. These input data cards. These input data cards define the geometry and identification of a cross section. The PLOT command is used to draw and label the section data for verifying cross section geometry.

After entering and verifying the section data, the SOLVE CENTROIDAL or SOLVE PRINCIPAL commands can be used to calculate and display cross section properties, fill out the FEM property cards, and add section and FEM property data card images to the data file.

After the FEA run, the SOLVE STRESS RECOVERY and SOLVE LOCAL COLLAPSE commands can be used for calculating stress data or section collapse coefficients.

The DIGITIZE DATA command should be used when a scaled drawing of the cross section and graphics tablet are available. This method can be used to quickly prepare the necessary section data card images. The ADD command should be used if a scaled drawing and graphics tablet are not available. The user must then enter section data at the keyboard.

The FEA element stresses and forces are required to use the SOLVE STRESS RECOVERY or SOLVE LOCAL COLLAPSE commands.

The VIEW function is used to selectively display a FEM. Model Geometry can be easily evaluated using a variety of VIEW commands. Some of the VIEW capabilities are:

- grid & element data checking
- nested rectangular, cylindrical, and spherical coordinate systems
- grid sorting
- one, two, and three dimensional element commands
- rotating
- zooming
- plotting by element types
- plotting by element property types
- plotting grids
- labeling current plot set
- labeling grids and elements
- adding element types to picture
- adding element property types to picture
- adding grids to picture
- adding grid and element labels to picture
- specifying character size
- showing individual grids or elements
- shrinking or expanding elements
- specifying maximum deformation
- overlaying undeformed and deformed pictures
- plotting by x, y, and z locations
- large or small color paper plots
- sorting of plot data
- specifying line size and pattern
- specifying different colors for paper plots

Many of the VIEW commands are turned on and off by entering the command and a y or n (y for yes, n for no). When the command to draw the picture is given, only the commands that are turned on are executed.


When the VIEW function is entered, a message saying checking and transforming XXX grid card images will appear. The XXX is the number of grid card images in the FEM file. All of these grids are transformed to the basic rectangular coordinate system if they are not already located in it. Then, a message saying checking and transforming XXX element card images will appear. Again the XXX is the number of element card images in the FEM file. Each element is then checked to see if all of the specified grids are in the FEM file. If a specified grid is not found for an element, a message will appear giving the grid and element identification. A hard copy will be made of any errors that are found. Any elements that have an error will not be drawn.

VIEW is useful as a pre and/or post-processing tool in helping quickly identify errors in FEM geometry, element connectivities, and element properties. It is also useful in evaluating and presenting the results of a FEA run. It should always be used before and after a FEA run to help verify the FEM.

APPENDIX A

SELECTED EXAMPLES OF

GRAFAX DISPLAYS




RX = -75 RY = 0
ENTER A VIEW COMMAND:

RZ = -75

CRAFAX

06-MAR-79




RX= -75. RY= 0
ENTER A VIEW COMMAND:

RZ= -75.

GRAFAX

06-MAR-79




RX= -75. RY= 0.
ENTER A VIEW COMMAND:

RZ= -75:

GRAFAX

06-MAR-79




RX = -75
SUBCASE 1
ENTER A VIEW COMMAND

RZ = -75

GRAFAX MAXD

05-MAR-79
-1.213109




RX= -75 RY= 0
SUBCASE 1
ENTER A VIEW COMMAND
DP 1
ENTER A VIEW COMMAND
AUX

RZ= -75

GRAFAX MAXD

08-MAR-79
-1.215109

ENTER A VIEW COMMAND




es
ENTER SUBCASE NUMBER:
i
ENTER ELEMENT TYPE (BAR, BEAM, TRIA, QUAD, TRI6, PENT, OR HEXA):
quad
*** CHOICES OF STRESS OUTPUT FOR QUAD ELEMENT

- NX NORMAL X STRESS
- NY NORMAL Y STRESS
- SH XY SHEAR STRESS
- PA PRINCIPAL STRESS ANGLE
- MJ MAJOR PRINCIPAL STRESS
- MIN MINOR PRINCIPAL STRESS
- MX MAXIMUM SHEAR STRESS

ENTER DESIRED STRESS OUTPUT:
nx
ENTER RANGE TO BE GRAPHED:
o11

06-MAR-79

AOS GRAFAX SUBCASE 1
TABLE EXAMPLE - MODERN ELEMENTS
RF24 - STATIC SOLUTION
500 LB VERTICAL LOAD




INTERNAL QUAD ID

ENTER RANGE TO BE GRAPHED:

SUBCASE

AOS GRAFAX
TABLE EXAMPLE - MODERN ELEMENTS
RF24 - STATIC SOLUTION
500 LB VERTICAL LOAD




INTERNAL HEXA ID

ENTER RANGE TO BE GRAPHED:

SUBCASE
ELEMENTS

AOS GRAFAX
TABLE EXAMPLE - MODERN
RF24 - STATIC SOLUTION
500 LB. VERTICAL LOAD




INTERNAL GRID ID

ENTER RANGE TO BE GRAPHED:

06-MAR-79

1


AOS GRAFAX SUBCASE
TABLE EXAMPLE - MODERN ELEMENTS
RF24 - STATIC SOLUTION
500 LB. VERTICAL LOAD



INTERNAL GRID ID

ENTER RANGE TO BE GRAPHED:

AOS GRAFAX
TABLE EXAMPLE - MODERN ELEMENTS
RF24 - STATIC SOLUTION
500 LB VERTICAL LOAD



ENTER RANGE TO BE GRAPHED:

report
ENTER A REPORT COMMAND:
es
ENTER SUBCASE NUMBER:
↓
ENTER ELEMENT TYPE (BAR, BEAM, TRIA, QUAD, TRI6, PENT, OR, HEXA):
quad
ENTER RANGE TO BE REPORTED:
o!!

TABLE EXAMPLE - MODERN ELEMENTS
 RF24 - STATIC SOLUTION
 500 LB VERTICAL LOAD

SUBCASE 1
 RANGE = 1 - 34 (ALL)
 STRESSES IN QUADRILATERAL ELEMENTS

STRESSES IN ELEM COORD	MAXIMUM	AT	MINIMUM	AT
NORMAL-X -FIBRE	1 308E+04	119	-1.016E+04	120
+FIBRE	1 007E+04	120	-1.316E+04	119
NORMAL-Y -FIBRE	2 858E+04	119	-1.182E+04	125
+FIBRE	1 177E+04	125	-2.871E+04	119
SHEAR-XY -FIBRE	7 298E+03	112	-6.646E+03	110
+FIBRE	6 625E+03	110	-7.300E+03	112

PRINCIPAL STRESSES	MAXIMUM	AT	MINIMUM	AT
MAJOR -FIBRE	2 866E+04	119	-2.593E+03	104
+FIBRE	1 335E+04	126	-1.308E+04	119
MINOR -FIBRE	1 300E+04	119	-1.342E+04	126
+FIBRE	2 349E+03	104	-2.879E+04	119

MAX SHEAR	MAXIMUM	AT	MINIMUM	AT
-FIBRE	8 736E+03	125	4 919E+01	132
+FIBRE	8 764E+03	125	8 253E+01	132

CONSTANT NEGATIVE FIBRE DISTANCE OF -5.000E-02
 CONSTANT POSITIVE FIBRE DISTANCE OF 5.000E-02

ENTER RANGE TO BE REPORTED:

** SUMMARY REPORT **

AOS GRAFAX

TABLE EXAMPLE - MODERN ELEMENTS
 RF24 - STATIC SOLUTION
 500 LB. VERTICAL LOAD

SUBCASE		10 (ALL)		STRESSES IN HEXAHEDRON SOLID ELEMENTS (CENTER)	
RANGE =	1 -	MAXIMUM	AT	MINIMUM	AT
NORMAL	- X	4.739E+00	161	-1.065E+01	162
	- Y	4.432E+00	161	-9.942E+00	162
	- Z	-5.008E+01	161	-1.971E+02	162
SHEAR	- XY	8.911E-01	163	-8.322E-01	162
	- YZ	4.421E-09	162	-1.773E+01	161
	- ZX	1.253E+01	161	-8.223E-09	162
PRINCIPAL	- A	1.209E+01	161	-1.971E+02	167
	- B	9.658E-02	165	-1.971E+02	162
	- C	4.659E+00	161	-1.120E+01	162
MEAN PRESSURE		7.257E+01	162	1.364E+01	161
OCTAHEDRAL SHEAR		9.384E+01	163	3.128E+01	161

ENTER RANGE TO BE REPORTED:

AOS GRAFAX

** SUMMARY REPORT **

06-MAR-79

TABLE EXAMPLE - MODERN ELEMENTS
RF24 - STATIC SOLUTION
500 LB. VERTICAL LOAD

SUBCASE	1	155(ALL)	LOAD VECTOR		
RANGE =	1 -		AT	MINIMUM	AT
TRANSLATION - X		0.0	101	0.0	101
TRANSLATION - Y		0.0	101	0.0	101
TRANSLATION - Z		0.0	101	-5.000E+02	121
ROTATION - X		0.0	101	0.0	101
ROTATION - Y		0.0	101	0.0	101
ROTATION - Z		0.0	101	0.0	101

ENTER RANGE TO BE REPORTED:

AOS GRAFAX

** SUMMARY REPORT **

06-MAR-79

TABLE EXAMPLE - MODERN ELEMENTS
RT24 - STATIC SOLUTION
500 LB VERTICAL LOAD

SUBCASE	1	FORCES OF SINGLE POINT CONSTRAINT		
		MAXIMUM	MINIMUM	AT
RANGE =	1 - 155(ALL)			
TRANSLATION - X		2.055E+00	-2.055E+00	200 165
TRANSLATION - Y		0.0	-3.233E-07	101 165
TRANSLATION - Z		1.339E+02	-2.490E+00	165 200
ROTATION - X		0.0	0.0	101 101
ROTATION - Y		0.0	0.0	101 101
ROTATION - Z		5.558E+02	-6.118E+02	112 114

ENTER RANGE TO BE REPORTED:

TABLE EXAMPLE - MODERN ELEMENTS
 RF24 - STATIC SOLUTION
 500 LB. VERTICAL LOAD

SUBCASE RANGE =	1 1 -	GRID POINT DISPLACEMENTS			
		155 (ALL) MAXIMUM	AT	MINIMUM	AT
TRANSLATION - X		5.897E-02	284	-3.131E-02	291
TRANSLATION - Y		4.625E-02	159	-3.565E-01	152
TRANSLATION - Z		4.515E-01	105	-1.213E+00	121
ROTATION - X		1.386E-01	129	-1.253E-01	121
ROTATION - Y		9.028E-02	120	-8.905E-02	122
ROTATION - Z		1.087E-02	153	-8.386E-03	150

ENTER RANGE TO BE REPORTED:

ENTER A PRINT COMMAND:

es

ENTER SUBCASE NUMBER:

1

ENTER ELEMENT TYPE (BAR, BEAM, TRIA, QUAD, TRIS, PENT, OR HEXA):

quad

ENTER INTERNAL ID OR RANGE TO BE LISTED:

10 20

ADS GRAFAX SURCASE 1 06-MAR-79
 TABLE EXAMPLE - MODERN ELEMENTS
 RP24 - STATIC SOLUTION
 500 LB. VERTICAL LOAD


STRESSES IN QUADRILATERAL ELEMENTS

ELEMENT ID.	FIBRE DISTANCE	STRESSES IN ELEMENT COORD SYSTEM	PRINCIPAL STRESSES (ZERO SHEAR)	MAX SHEAR				
		NORMAL-X NORMAL-Y SHEAR-XY	MAJOR MINOR					
110	-4.999998E-02 4.999998E-02	-4.018931E+03 3.876185E+03	-1.503327E+03 1.528605E+03	-6.646399E+03 6.625457E+03	-50.1904 40.1026	3.955554E+03 9.455855E+03	-9.558262E+03 -3.991067E+03	6.765906E+03 6.723461E+03
111	-4.999998E-02 4.999998E-02	7.836625E+03 -8.097367E+03	-4.987211E+03 4.928758E+03	-3.880444E+03 3.929240E+03	-15.5909 74.4432	3.919395E+03 6.816689E+03	-6.460977E+03 -9.191230E+03	7.494684E+03 7.603934E+03
112	-4.999998E-02 4.999998E-02	2.195030E+03 -2.383327E+03	-4.591160E+03 4.441004E+03	7.297848E+03 -7.500493E+03	22.6823 -57.5283	6.855926E+03 9.087283E+03	-9.223150E+03 -7.030623E+03	8.041543E+03 8.058613E+03
113	-4.999998E-02 4.999998E-02	-6.454422E+03 6.370203E+03	-1.410895E+03 1.234805E+03	5.213305E+03 -5.232099E+03	57.8069 -32.0603	1.858548E+03 9.627160E+03	-9.723959E+03 -1.932152E+03	5.791190E+03 5.779656E+03
114	-4.999998E-02 4.999998E-02	-4.495266E+02 4.615256E+02	2.078357E+02 -2.418520E+02	1.962442E+02 -1.807846E+02	74.5656 -13.6157	2.012671E+02 5.053147E+02	-5.037080E+02 -2.848508E+02	3.824875E+02 3.950826E+02
115	-4.999998E-02 4.999998E-02	-7.370735E+02 7.293440E+02	-1.122494E+03 1.110140E+03	-1.602607E+01 -2.601710E-01	-2.3771 -89.8608	-7.364982E+02 1.110140E+03	-1.123159E+03 7.293440E+02	1.933755E+02 1.933982E+02
116	-4.999998E-02 4.999998E-02	-4.736027E+03 4.663780E+03	-1.158709E+03 1.134609E+03	2.512033E+02 -2.604717E+02	86.0027 -4.1984	-1.141234E+03 4.682910E+03	-4.763582E+03 1.115982E+03	1.886174E+03 1.783715E+03
117	-4.999998E-02 4.999998E-02	-4.664715E+03 4.564699E+03	1.155459E+04 -1.161839E+04	9.790474E+02 -9.519954E+02	86.5560 -3.3551	1.161342E+04 4.620588E+03	-4.713633E+03 -1.167420E+04	8.163527E+03 8.147355E+03
118	-4.999998E-02 4.999998E-02	1.307996E+04 -1.318567E+04	2.858289E+04 -2.871488E+04	-1.090306E+03 1.100637E+03	-85.9966 4.0264	2.855890E+04 -1.307820E+04	1.300366E+04 -2.870216E+04	7.827621E+03 7.856977E+03
120	-4.999998E-02 4.999998E-02	-1.016316E+04 1.007212E+04	1.700465E+03 -1.826179E+03	-1.142532E+03 1.113549E+03	-84.5665 5.3009	1.849145E+03 1.017543E+04	-1.027184E+04 -1.929498E+03	6.060492E+03 6.052465E+03
121	-4.999998E-02 4.999998E-02	-1.431110E+03 1.422545E+03	-2.350651E+03 2.318992E+03	1.84537E+02 -1.851226E+02	10.9364 -78.7793	-1.395445E+03 2.355716E+03	-2.386316E+03 1.388820E+03	4.954355E+02 4.849400E+02

INTERNAL ID RANGE 10 - 20
 ENTER INTERNAL ID OR RANGE TO BE LISTED:

06-MAR-79

ENTER A SECTION COMMAND:
SP




06-MAR-79

GRAFAX
 PBAR 98
 +PA0098 -5.641 101
 +PB0098 0.335 -4.574
 ENTER A SECTION COMMAND: 0.225

6.088 125.562 38.540
 -7.544 -0.156 2.813
 0.0

0.081
 4.313

6.017 -3.040




SECTION 98

CENTROID		
5.743	7.556	
SHEAR CENTER		
10.570	12.125	
BETA		
	-23.188	
IH IV		
125.562	38.540	
TORSION CONSTANT		
	.0812	
PERIMETER AREA		
	6.0880	
KW	KHV	KHH
3.1591	-.9056	4.6954
WARPING CONSTANT		
	1055.15	
PLASTIC MOMENT FACTORS		
VP	HP	
13.8571	25.0615	

ENTER A SECTION COMMAND:
SC

06-MAR-79



GRAFAX

98

101

6.088

112.071

52.032

0.081

06-MAR-79

+PA0098

-6.986

-1.983

-6.996

2.827

4.284

2.857

4.334 -5.163


+PB0098

0.335

0.225

-31.497

ENTER A SECTION COMMAND:



SECTION 98

CENTROID	5.743	7.556
SHEAR CENTER	10.570	12.125
IVH	-31.497	
IH	112.071	52.032
IV		
TORSION CONSTANT	.0812	
PERIMETER AREA	6.0880	
KVV	3.1591	
KHV	-.9056	
KHH	4.6954	
WARPING CONSTANT	1055.15	
PLASTIC MOMENT FACTORS		
VP	18.2263	
HP		24.7316

U I E U H E L P M E N U

COMMAND

AB --- ADD BEAM LABEL (PID)
 ABL --- ADD BEAM PROPERTY (PID)
 ABP --- ADD BEAM LABEL
 AG --- ADD GRID LABEL
 AGL --- ADD GRID LABEL
 AH --- ADD HEXA LABEL
 AHL --- ADD HEXA LABEL
 AHP --- ADD HEXA PROPERTY (PID)
 AP --- ADD PENT LABEL
 APL --- ADD PENT LABEL
 APP --- ADD PENT PROPERTY (PID)
 AQ --- ADD QUAD LABEL
 AQL --- ADD QUAD LABEL
 ADP --- ADD QUAD PROPERTY (PID)
 AT --- ADD TRIA LABEL
 ATL --- ADD TRIA LABEL
 ATP --- ADD TRIA PROPERTY (PID)
 AUS --- ADD UNDEFORMED SHAPE
 CN --- CHARGE NUMBER
 CP --- CALCOMP PLOT (V) (N)
 CPC --- CALCOMP PEN COLOR (VALUE)
 CPCS --- CALCOMP PLOT CHARACTER SIZE (VALUE)
 CPL --- CALCOMP PLOT LENGTH (VALUE)
 CPU --- CALCOMP PLOT WIDTH (VALUE)
 CS --- CHARACTER SIZE (VALUE)
 CTS --- CHARACTER TITLE CHARACTER SIZE (VALUE)
 DP --- DASH PATTERN (VALUE)
 GS --- GRID SIZE (VALUE)
 H --- CREATES THIS DISPLAY
 HC --- HARD COPY
 LCU --- LIST COMMAND VALUES
 LB --- LABEL BEAM (V) (N)
 LG --- LABEL GRID (V) (N)
 LH --- LABEL HEXA (V) (N)
 LO --- LIST OUTPUT
 LP --- LABEL PENT (V) (N)
 LQ --- LABEL QUAD (V) (N)
 LS --- LINE SIZE (VALUE)
 LT --- LABEL TRIA (V) (N)
 PCT --- ROUTE COMMAND TIPPING (VALUE)
 PD --- MAXIMUM DEFORMATION (VALUE)
 PM --- MODAL MOVE
 MP --- MAGNETICS PLOT (SID)
 NP --- NEW PAGE
 P --- PLOT MODEL USING CURRENT INFORMATION
 PB --- PLOT BEAM (V) (N)
 PBP --- PLOT BEAM PROPERTY (V,PID) (N)
 PDS --- PLOT DEFORMED SHAPE (V,SID) (N)
 PG --- PLOT GRID (V) (N)
 PH --- PLOT HEXA (V) (N)
 PHP --- PLOT HEXA PROPERTY (V,PID) (N)
 PL --- PLOT LOCATION (V) (N)
 PO --- PLOT OUTLINE (V) (N)
 PP --- PLOT PENT (V) (N)
 PPP --- PLOT PENT PROPERTY (V,PID) (N)
 PQ --- PLOT QUAD (V) (N)
 POP --- PLOT QUAD PROPERTY (V,PID) (N)
 PT --- PLOT TRIA (V) (N)
 PTP --- PLOT TRIA PROPERTY (V,PID) (N)
 R --- RETURN
 RB --- RING BELL

RM --- REMOTE NUMBER (VALUE)
 RLS --- REPLOT LAST SET (VALUE)
 RX --- ROTATE X (VALUE)
 RY --- ROTATE Y (VALUE)
 RZ --- ROTATE Z (V) (N)
 S --- SORT (V) (N)
 SCT --- SHOW COMMAND TIPPING (VALUE)
 SE --- SHOW ELEMENT (ID)
 SF --- SHRINK FACTOR (VALUE)
 SO --- SHOW GRID (ID)
 SM --- STATIC MOVE (V) (N)
 SP --- SHRINK PLOT (V) (N)
 T --- TITLE (V) (N)
 U --- USERID (Y) (N)
 Z --- ZOOM (Y) (N)

ENTER LETTER(S) AT LEFT & PARAMETER(S) TO PERFORM COMMAND DESCRIBED


ENTER A VIEW COMMAND:

RX= -75 RY= 0
ENTER A VIEW COMMAND:

RZ= -75.

GRAFAX

06-MAR-79




RX= -75. RY= 0
ENTER A VIEW COMMAND:

RZ= -75

CRAFAX

06-MAR-79




RX- -75. RY- 0.
ENTER A VIEW COMMAND:

RZ- -75.

GRAFAX


06-MAR-79



RY = 0 RZ = -75
SUBCASE 1
ENTER A VIEW COMMAND

06-MAR-79
MAXD -1.213169

CRAFAX



RZ= -75

RY= 0

CRNFAX MAXD 00-MAR-79
-1.213109

SURFACE


ENTER A VIEW COMMAND

OR 1

ENTER A VIEW COMMAND

AUX.

ENTER A VIEW COMMAND



G R A P H H E L P M E N U

COMMAND			
AL	APPLIED LOAD		
CF	CONSTRAINT FORCE		
CS	CHARACTER SIZE	-----	(VALUE)
D	DISPLACEMENT		
EF	ELEMENT FORCE		
ES	ELEMENT STRESS		
H	CREATES THIS DISPLAY		
HC	HARD COPY		
LO	LIST OUTPUT		
LS	LINE SIZE	-----	(VALUE)
NP	NEW PAGE		
R	RETURN		
RB	RING BELL		

ENTER A GRAPH COMMAND:

es
ENTER SUBCASE NUMBER:
i
ENTER ELEMENT TYPE (BAR, BEAM, TRIA, QUAD, TRI6, PENT, OR HEXA):
quad
*** CHOICES OF STRESS OUTPUT FOR QUAD ELEMENT


NX	NORMAL X STRESS
NY	NORMAL Y STRESS
SH	XY SHEAR STRESS
PA	PRINCIPAL STRESS ANGLE
MJ	MAJOR PRINCIPAL STRESS
MN	MINOR PRINCIPAL STRESS
MX	MAXIMUM SHEAR STRESS

ENTER DESIRED STRESS OUTPUT:
nx
ENTER RANGE TO BE GRAPHED:
o11

AOS GRAFAX
TABLE EXAMPLE - MODERN ELEMENTS
RF24 - STATIC SOLUTION
500 LB VERTICAL LOAD

SUBCASE 1

06-MAR-79



INTERNAL QUAD ID

ENTER RANGE TO BE GRAPHED:

R E P O R T H E L P M E N U

COMMAND	
AL	APPLIED LOAD
CF	CONSTRAINT FORCE
CS	CHARACTER SIZE ----- (VALUE)
D	DISPLACEMENT
EF	ELEMENT FORCE
ES	ELEMENT STRESS
H	CREATES THIS DISPLAY
HC	HARD COPY
LO	LIST OUTPUT
LS	LINE SIZE ----- (VALUE)
NP	NEW PAGE
R	RETURN
RB	RING BELL

ENTER A REPORT COMMAND:

report
ENTER A REPORT COMMAND:
es
ENTER SUBCASE NUMBER:
1
ENTER ELEMENT TYPE (BAR, BEAM, TRIA, QUAD, TRI6, PENT, OR, HEXA):
quad
ENTER RANGE TO BE REPORTED:
o:1

AOS GRAFAX

** SUMMARY REPORT **

06-MAR-79

TABLE EXAMPLE - MODERN ELEMENTS
REP24 - STATIC SOLUTION
500 LB VERTICAL LOAD

SUBCASE 1
RANGE = 1 - 34(ALL)
STRESSES IN QUADRILATERAL ELEMENTS

STRESSES IN ELEM COORD	MAXIMUM	AT	MINIMUM	AT
NORMAL-X -FIBRE	1 308E+04	119	-1 016E+04	120
NORMAL-X +FIBRE	1 007E+04	120	-1 316E+04	119
NORMAL-Y -FIBRE	2 858E+04	119	-1 182E+04	125
NORMAL-Y +FIBRE	1 177E+04	125	-2 871E+04	119
SHEAR-XY -FIBRE	7 298E+03	112	-6 646E+03	110
SHEAR-XY +FIBRE	6 625E+03	110	-7 300E+03	112

PRINCIPAL STRESSES	MAXIMUM	AT	MINIMUM	AT
MAJOR -FIBRE	2 866E+04	119	-2 593E+03	104
MAJOR +FIBRE	1 335E+04	126	-1 308E+04	119
MINOR -FIBRE	1 300E+04	119	-1 342E+04	126
MINOR +FIBRE	2 349E+03	104	-2 879E+04	119

MAX SHEAR	MAXIMUM	AT	MINIMUM	AT
-FIBRE	8 736E+03	125	4 919E+01	132
+FIBRE	8 764E+03	125	8 253E+01	132

CONSTANT NEGATIVE FIBRE DISTANCE OF -5.000E-02
CONSTANT POSITIVE FIBRE DISTANCE OF 5.000E-02

ENTER RANGE TO BE REPORTED:

P R I N T H E L P M E N U

COMMAND	----	
AL	----	APPLIED LOAD
CF	----	CONSTRAINT FORCE
CS	----	CHARACTER SIZE ----- (VALUE)
D	----	DISPLACEMENT
EF	----	ELEMENT FORCE
ES	----	ELEMENT STRESS
H	----	CREATES THIS DISPLAY
HC	----	HARD COPY
LO	----	LIST OUTPUT
LS	----	LINE SIZE ----- (VALUE)
NP	----	NEW PAGE
R	----	RETURN
RB	----	RING BELL

ENTER A PRINT COMMAND:

ENTER A PRINT COMMAND:

05

ENTER SUBCASE NUMBER:

1

ENTER ELEMENT TYPE (BAR, BEAM, TRIA, QUAD, TRIG, PENT, OR HEXA):

quad

ENTER INTERNAL ID OR RANGE TO BE LISTED:

10 20

608 GRAFAX
TABLE EXAMPLE - MODERN
RF24 - STATIC SOLUTION
500 LB. VERTICAL LOAD

1

06-MAR-79

STRESSES IN QUADRILATERAL ELEMENTS

ELEMENT ID.	FIBRE DISTANCE	STRESSES IN ELEMENT COORD SYSTEM		PRINCIPAL STRESSES (ZERO SHEAR)		MAX SHEAR
		NORMAL-X	SHEAR-XY	MAJOR	MINOR	
110	-4.999998E-02 4.999998E-02	-4.018931E+03 3.878186E+03	-1.583827E+03 6.646390E+03	3.955554E+03 9.455855E+03	-9.558262E+03 -2.991667E+03	6.756906E+03 8.723461E+03
111	-4.999998E-02 4.999998E-02	7.836625E+03 -8.097367E+03	-3.880414E+03 3.889240E+03	8.919395E+03 6.916889E+03	-6.069777E+03 -9.191238E+03	7.494684E+03 7.603934E+03
112	-4.999998E-02 4.999998E-02	2.189230E+03 -2.383827E+03	-4.559160E+03 4.441004E+03	7.297840E+03 -7.300453E+03	6.899926E+03 9.087293E+03	8.041543E+03 8.058613E+03
113	-4.999998E-02 4.999998E-02	-6.454422E+03 6.379203E+03	-1.410395E+03 1.324895E+03	5.213280E+03 -5.200039E+03	1.858542E+03 9.627160E+03	5.791199E+03 5.779666E+03
114	-4.999998E-02 4.999998E-02	-4.495266E+02 4.615256E+02	2.070857E+02 -2.410590E+02	1.962442E+02 -1.807846E+02	2.812671E+02 6.053147E+02	3.824875E+02 3.950828E+02
115	-4.999998E-02 4.999998E-02	-7.370735E+02 7.293449E+02	-1.122494E+03 1.110140E+03	-1.502687E+01 -8.601710E-01	-7.364892E+03 1.110140E+03	1.933755E+02 1.903992E+02
116	-4.999998E-02 4.999998E-02	-4.736027E+03 4.663789E+03	-1.158788E+03 1.134603E+03	2.518023E+02 -2.804717E+02	-1.141234E+03 4.682910E+03	1.806174E+03 1.783715E+03
117	-4.999998E-02 4.999998E-02	-4.854715E+03 4.564699E+03	1.155450E+04 -1.161039E+04	9.790474E+02 -9.519954E+02	-7.364892E+03 1.110140E+03	1.933755E+02 1.903992E+02
119	-4.999998E-02 4.999998E-02	1.307996E+04 -1.315567E+04	2.858260E+04 -2.871468E+04	-1.090306E+03 1.106637E+03	2.655909E+04 -1.999202E+04	7.827621E+03 7.856977E+03
120	-4.999998E-02 4.999998E-02	-1.015316E+04 1.007212E+04	1.740652E+03 -1.826179E+03	-1.125836E+03 1.113540E+03	1.849145E+03 1.017543E+04	6.060492E+03 6.052465E+03
121	-4.999998E-02 4.999998E-02	-1.431100E+03 1.422545E+03	-2.358651E+03 2.318992E+03	1.845737E+02 -1.851226E+02	-1.396445E+03 2.355716E+03	4.954355E+02 4.849480E+02

INTERNAL ID RANGE - 10 - 20
ENTER INTERNAL ID OR RANGE TO BE LISTED:

SECTION HELP MENU

COMMAND	ADD	-----	(VALUE)
A	CHANGE	-----	
C	CHARACTER SIZE	-----	(VALUE)
CS	DIGITIZE DATA		
DD	DELETE		
D	DELETES THIS DISPLAY		
H	HARD COPY		
HC	LIST OUTPUT		
L	LINE SIZE	-----	(VALUE)
LO	NEW PAGE		
LS	PLOT		
NP	RETURN		
P	RING BELL		
R	RETRIEVE SECTION DATA	-----	(PID)
RB	SOLVE CENTROIDAL		
RSD	SOLVE LOCAL COLLAPSE		
SC	SOLVE PRINCIPAL		
SLC	SOLVE STRESS RECOVERY		
SP			
SSR			


DIGITIZING SUBCOMMANDS

C	CONNECT TO EXISTING NODE WITH A LINE
J	START FROM EXISTING NODE WITH A LINE
O	RE-ORIENT DRAWING ON TABLET
T	CHANGE THICKNESS
P	DIGITIZE A STRESS RECOVERY POINT

ENTER A SECTION COMMAND:

ENTER A SECTION COMMAND:
SP


06-MAR-79



GRAFAX 98 101
 PBAR -5.641 -4.574
 +PA0098 0.335 0.225
 +PB0098
 ENTER A SECTION COMMAND:

6.088 125.562 38.540
 -7.544 -0.156 2.813
 0.0

06-MAR-79
 0.081
 4.313 6.017 -3.040




SECTION 98

CENTROID
 5.743 . 7.556
 SHEAR CENTER
 10.570 . 12.125
 BETA
 -23.188
 I_H I_V
 125.562 38.540
 TORSION CONSTANT
 .0812
 PERIMETER AREA
 6.0880
 K_{VV} K_{HV} K_{HH}
 3.1591 -.9056 4.6954
 WARPING CONSTANT
 1055.15
 PLASTIC MOMENT
 FACTORS
 V_P H_P
 13.8571 25.0615

ENTER A SECTION COMMAND:
SC


06-MAR-79



GRAFAX
 PBAR 98 101 6.088 112.071 52.032 0.081
 +PA0098 -6.986 -1.983 -6.996 2.827 4.284 2.857
 +PB0098 0.335 0.225 -31.497
 ENTER A SECTION COMMAND:

06-MAR-79

4.334 -5.163



SECTION 98

CENTROID
 5.743 , 7.556
 SHEAR CENTER
 10.570 , 12.125
 IVH
 -31.497
 IH IV
 112.071 52.032
 TORSION CONSTANT
 .0812
 PERIMETER AREA
 6.0880
 KVV KHV KHH
 3.1591 -.9056 4.6954
 WARPING CONSTANT
 1055.15
 PLASTIC MOMENT
 FACTORS
 VP HP
 18.2263 24.7316

R U N H E L P M E N U

COMMAND	----	ADD CARD	
A	----	ADD DEFAULT DECK	
ADD	----	SUBMIT A SELECTED BATCH RUN	
B	----	CHANGE CARD	
C	----	CHARACTER SIZE	----- (VALUE)
CS	----	DELETE CARD	
D	----	CREATES THIS DISPLAY	
H	----	HARD COPY	
HC	----	INSERT BLANK LINE	
I	----	LIST CARD	
L	----	LINE SIZE	----- (VALUE)
LS	----	NEW PAGE	
NP	----	RETURN	
R	----	RING BELL	
RB	----	SUBMIT FILE FOR BATCH RUN & END	
S	----		

ENTER LETTER(S) AT LEFT TO PERFORM COMMAND DESCRIBED.

ENTER A R U N C O M M A N D :

E D I T H E L P M E N U

COMMAND	----	ADD CONNECTION	
AC	----	ADD GRID	
AG	----	ADD GENERATING DATA	
AGD	----	ADD MISCELLANEOUS	
AM	----	CHANGE CONNECTION	
CC	----	CHANGE GRID	
CG	----	CHANGE GENERATING DATA	
CGD	----	CHANGE MISCELLANEOUS	
CM	----	CHARACTER SIZE	----- (VALUE)
CS	----	DELETE CONNECTION	
DC	----	DELETE GRID	
DG	----	DELETE GENERATING DATA	
DGD	----	DELETE MISCELLANEOUS	
DM	----	GENERATE NEW DATA	
GND	----	CREATES THIS DISPLAY	
H	----	HARD COPY	
HC	----	INSERT CONNECTION	
IC	----	INSERT GRID	
IG	----	INSERT GENERATING DATA	
IGD	----	INSERT MISCELLANEOUS	
IM	----	LIST CONNECTION	
LC	----	LIST GRID	
LG	----	LIST GENERATING DATA	
LGD	----	LIST MISCELLANEOUS	
LM	----	LINE SIZE	----- (VALUE)
LS	----	NEW PAGE	
NP	----	RETURN	
R	----	RING BELL	
RB	----		

E N T E R A N E D I T C O M M A N D :

CHAN.CMD

EDIT

NP

CS 4

AGD

GRID,1,,1.0,0.0,0.0

GRID,2,,0.5,0.0,0.0

GRID,3,,0.0,0.0,0.0

GRID,4,,0.0,0.5,0.0

GRID,5,,0.0,1.0,0.0

GRID,6,,0.0,1.5,0.0

GRID,7,,0.0,2.0,0.0

GRID,8,,0.5,2.0,0.0

GRID,9,,1.0,2.0,0.0

-.10,--,0.5,--,9

-.100,--,6.0,--,1

-.1000,--,4.0,--,1

GND

HC

NP

DGD 1 999

AGD

CQUAD4,1,1,1,2,12,11

-.1,1,1,1,1,--,7

-.10,10,10,10,10,--,8

-.100,1,100,100,100,--,1

-.1000,10,1000,1000,1000,--,1

GND

HC

R

END

READY

ENTER AN EDIT COMMAND:

ENTER AN EDIT COMMAND:

ENTER DATA FOR CARD:

1 GRID,1,1,0,0,0,0,0

A D D E D

ENTER DATA FOR CARD:

2 GRID,2,0,5,0,0,0,0

A D D E D

ENTER DATA FOR CARD:

3 GRID,3,0,0,0,0,0,0

A D D E D

ENTER DATA FOR CARD:

4 GRID,4,0,0,0,5,0,0

A D D E D

ENTER DATA FOR CARD:

5 GRID,5,0,0,1,0,0,0

A D D E D

ENTER DATA FOR CARD:

6 GRID,6,0,0,1,5,0,0

A D D E D

ENTER DATA FOR CARD:

7 GRID,7,0,0,2,0,0,0

A D D E D

ENTER DATA FOR CARD:

8 GRID,8,0,5,2,0,0,0

A D D E D

ENTER DATA FOR CARD:

9 GRID,9,1,0,2,0,0,0

A D D E D

ENTER DATA FOR CARD:

10,10,0,0,0,5,0,0

A D D E D

ENTER DATA FOR CARD:

11,100,0,0,0,0,0,0,1

A D D E D

ENTER DATA FOR CARD:

12,1000,0,4,0,0,0,1

A D D E D

ENTER DATA FOR CARD:

ENTER AN EDIT COMMAND:
THE FOLLOWING HAS BEEN GENERATED & ADDED

360 GRID CARD IMAGES.
ENTER AN EDIT COMMAND:

ENTER AN EDIT COMMAND:
DELETE
ENTER AN EDIT COMMAND:
ENTER DATA FOR CARD:
1 COUAD4.1.1.1.2.12.11
ADD ED
ENTER DATA FOR CARD:
2 -.1.-.1.1.1.-.7
ADD ED
ENTER DATA FOR CARD:
3 -.10.-.10.10.10.10.-.8
ADD ED
ENTER DATA FOR CARD:
4 -.100.1.100.100.100.-.1
ADD ED
ENTER DATA FOR CARD:
5 -.1000.10.1000.1000.1000.-.1
ADD ED
ENTER DATA FOR CARD:
ENTER AN EDIT COMMAND:
THE FOLLOWING HAS BEEN GENERATED & ADDED
288 ELEMENT CARD IMAGES.
ENTER AN EDIT COMMAND:

CHECKING AND TRANSFORMING
UNSORTED GRIDS APPEARED.
THEY HAVE BEEN SORTED.
D A T A S A U E D
CHECKING AND TRANSFORMING
ENTER A VIEW COMMAND:
RX 20
ENTER A VIEW COMMAND:
RY 030
ENTER A VIEW COMMAND:
P

360 GRID CARD IMAGES.

288 ELEMENT CARD IMAGES.

06-MAR-79

GRAFAX

RZ= 0.

RX= 20. RY= 30.
ENTER A VIEW COMMAND:

