


## WORKSHOP 14

### *Using Groups and Lists*




### Objectives:

- Build a finite element model that includes element properties and boundary conditions.
- Use lists to identify parts of the model with specified attributes.
- Explore the Group Display mode.



**Model Description:**

In this exercise you will import or construct a portion of a fairing. Shown below is a drawing of the assembled structure and its dimensions. Use curves and surfaces to define the fairing geometry. The finite element model will consist of 2-dimensional elements with 1-dimensional elements applied at various edges of the geometry. The 1-dimensional elements will represent stiffeners for the structure.

**Figure 14-1**

Analysis Code	P3/FEA	
Element Types	Bar2 (horizontal fairing edges) Quad4 (fairing surface)	
Material Name	Alum_1	Alum_2
Modulus of Elasticity, E (psi)	1.05E7	1.18E7
Poisson's Ratio, $\nu$	0.33	0.33
Density, $\rho$ (lb/in <sup>3</sup> )	2.6E-4	2.4E-4
Model Thickness	1.5 - Y/160.	
Model Temperature Distribution	200.-(150./160.)X	

**Table 14-1**

## Suggested Exercise Steps:

- Create a new database and name it **fairing.db**. Select **Default** for the *Tolerance* and **MSC/NASTRAN** for the *Analysis Code*.
- Either import the Geometry and Finite Element model from the neutral file **fairing.out** or create the model using Figure 14-1.
- Create the points and curves that represent the outline of the fairing.


Point 1 (XYZ method): [30,0,0];

curve 1 (XYZ method): vector length=<0,120,0>;  
origin=[50,40,0]

curve 2 (point method): between points 1 and 2.

- Sweep Curves 1 & 2 through 360° angles about the center-line of the fairing in 4 steps using the Surface Revolve method.

- a) Seed the circumference of the fairing at the upper edge with 9 nodes per quarter of the circumference.



- b) Create non-uniform seed distributions along the vertical edge of the fairing represented by Curve 1 & 2..

Curve 1, L2 = 10, L1 = 7

Curve 2, L2 = 7, L1 = 4

- c) Create the mesh for the surface using Quad4 elements.
- d) Create Bar2 elements along the circumference representing the edges of the upper cylinder of the lower cone.
- Create a group containing only the finite element model. Name the group FEM. Post only that group to the viewport.
  - Create the materials for the fairing. Materials **alum\_1** and **alum\_2** will be applied to the top (cylindrical) and bottom (tapered) portions of the fairing respectively. Use Table 14-1 to define the Material Properties.
  - Define fields that represent the varying **thickness** and **temperature** distribution. Use Table 14-1 to define the fields.
  - Create the element properties which include the material definitions and the varying thickness. Use the names **prop\_1** and **prop\_2** for the element property names.
  - Define the model's varying temperature distribution. Use the name **temp** for the temperature set name.
  - Use Lists and Groups to display the Quad elements that have the following attributes:
    - Material:alum\_1 (MATRL.1)
    - Thickness:> 0.98
    - Temperature: > 230.0

Create a new group named **Common\_Quads** and add these elements to that group. Plot the temperature contours on these elements. Reset Graphics.

- Post only the group named FEM and change the render style to hidden line (the bars will disappear).
- Create a group containing only the bar elements. Name the group **BARS**.
- Change to group display mode and modify the FEM and BARS render style as follows:

Group	Render Style	Shade Color	Entity Labels
<b>FEM</b>	<b>Hidden Line</b>	<b>Cyan</b>	<b>Off</b>
<b>BARS</b>	<b>Wireframe</b>	<b>Yellow</b>	<b>Off</b>

- Change the render style for the group BARS to **Wireframe/Accurate**.

## Exercise Procedure:

1. Create a new database and name it **fairing.db**. Select **Default** for the *Tolerance* and **MSC/NASTRAN** for the *Analysis Code*.

### File/New...

*New Database Name*

**fairing**

**OK**

### New Model Preference

*Tolerance*

◆ **Default**

*Analysis Code:*

**MSC/NASTRAN**

**OK**

2. Either import the Geometry and Finite Element model from the neutral file **fairing.out** or create the model using Figure 14-1.

If you are going to import the Geometry and Finite Element model of the fairing, perform the following import procedure, then skip to step 11. If you are going to build the fairing model, skip to step 3.

**File/Import...**

<i>Object:</i>	Model
<i>Source:</i>	Neutral
<i>Import File</i>	fairing.out
<span style="border: 1px solid black; padding: 2px 10px;">Apply</span>	

Respond **Yes** when asked to continue on the *Import Summary* form.

To see what was just imported, go to **Group/Modify** and look at the *Member List*. Both geometry (points, curves and surfaces) and finite elements (nodes and elements) have been imported into the default\_group. Click on **OK** to close the form. To see what kinds of elements were imported, select the **Finite Elements** radio button, then **Show/Element/Attributes**, highlight all the elements and hit **Apply**. Scroll down through the spreadsheet to see that both Quad4 and Bar2 elements are in the model.

Now create a group containing only the finite element model.

**Group/Create...**

<i>New Group Name</i>	FEM
<i>Group Contents</i>	Add All FEM
<span style="border: 1px solid black; padding: 2px 10px;">Apply</span>	

Go to Step 11.

3. Create the points and curves that represent the outline of the fairing.

Point 1 [30,0,0];  
Curve 1: vector length=<0,120,0>; origin=[50,40,0]

Curve 2: between points 1 and 2.

**Create  
Model  
Geometry**

### ◆ Geometry

<i>Action:</i>	<b>Create</b>
<i>Object:</i>	<b>Point</b>
<i>Method:</i>	<b>XYZ</b>
<i>Point Coordinate List</i>	<b>[30, 0, 0]</b>
<b>Apply</b>	

Turn on labels and display lines using the **Show Labels** and **Display Lines** icons,




Now you will create curves that represent the profile of the fairing. They will be swept to create the fairing's surface.

<i>Action:</i>	<b>Create</b>
<i>Object:</i>	<b>Curve</b>
<i>Method:</i>	<b>XYZ</b>
<i>Vector Coordinate List</i>	<b>&lt;0, 120, 0&gt;</b>
<i>Origin Coordinate List</i>	<b>[50, 40, 0]</b>
<b>Apply</b>	

Next change the *Method* option menu to **Point**.

<i>Action:</i>	<b>Create</b>
<i>Object:</i>	<b>Curve</b>
<i>Method:</i>	<b>Point</b>
<i>Starting Point List</i>	<b>Point 1</b>
<i>Ending Point List</i>	<b>Point 2</b>
<b>Apply</b>	


Your model should appear as follows:



4. Create the fairing from an assembly of quarter circular surfaces defined by revolving curves 1 and 2 about the fairing's vertical center line.

<i>Action:</i>	<input type="button" value="Create"/>
<i>Object:</i>	<input type="button" value="Surface"/>
<i>Method:</i>	<input type="button" value="Revolve"/>
<i>Surface Type</i>	<input checked="" type="checkbox"/> PATRAN 2 Convention
<i>Axis</i>	<input type="button" value="Coord 0.2"/>
<i>Total Angle</i>	<input type="button" value="360"/>
<i>Surface per Curve</i>	<input type="button" value="4"/>
<i>Curve List</i>	<input type="button" value="Curve 1, 2"/>
<input type="button" value="Apply"/>	
Change the view <i>Angle</i> to <b>30 0 0</b>	
<b>Viewing/Angles...</b>	
Angles	<input type="button" value="30, 0, 0"/>
<input type="button" value="Apply"/>	
<input type="button" value="Cancel"/>	


Your model should appear as follows:



**Create Mesh Seeds**

5. Create a finite element mesh that has the following attributes:

Along the circumferential edges create 4 node Quad elements every 10°



◆ **Finite Elements**

Action:

**Create**

Object:

**Mesh Seed**

Type:

**Uniform**

◆ **Number of Elements**


Number =

**9**


Curve List

Select the Upper Circumferential Edges of Surfaces 1 through 4. See the figure below

**Apply**



In the vertical direction (y-direction), define a smoothly transitioning mesh density, the elements along the top of the cylinder are 2.5 times as large as those along the bottom edge (tapered end) of the fairing.



Action:

Create

Object:

Mesh Seed

Type:

One Way Bias

◆ L1 and L2

L1 =

7

L2 =

10

Curve List

Curve 1

**Apply***Action:***Create***Object:***Mesh Seed***Type:***One Way Bias**◆ **L1 and L2***L1 =***4***L2 =***7***Curve List***Curve 2****Apply**

Now that the seed has been created you will mesh the model.

*Action:***Create***Object:***Mesh***Type:***Surface***Element Topology***Quad 4***Surface List*


Select All Surfaces

**Apply**

Turn of display lines and labels by using the appropriate icons.



Your model should appear as follows:



Mesh the horizontal (circumferential) edges of each surface with two-noded bar elements.

*Action:*

**Create**

*Object:*

**Mesh**

*Type:*


**Curve**

*Element Topology*

**Bar 2**

*Curve List*

Select the surface edges shown below. A hint on selecting the appropriate edges. Set the view to the default, then use click and drag picking technique.



Also you may want to Erase all FEM in **Display/Plot/Erase...** to make the selection easier. When you are done remember to replot the FEM.

**Apply**

Equivalence the Finite Elements to reduce the number of elements by eliminating duplicate nodes.

*Action:*

**Equivalence**

*Object:*

**All**

*Type:*

**Tolerance Cube**

**Apply**

6. Create a group containing only the finite element model. Name the group FEM. Post only that group to the viewport

**Group/Create...**

*New Group Name*

**FEM**

**Unpost All Other Groups**

*Group Contents*

**Add All FEM**

**Apply**

**Cancel**

7. Create the materials for the fairing. Materials **alum\_1** and **alum\_2** will be applied to the top (cylindrical) and bottom (tapered) portions of the fairing respectively. Use Table 14-1 to define the Material Properties.

◆ **Materials**

<i>Action:</i>	<b>Create</b>
<i>Object:</i>	<b>Isotropic</b>
<i>Method:</i>	<b>Manual Input</b>
<i>Material Name</i>	<b>alum_1</b>
<b>Input Properties...</b>	
<i>Constitutive Model:</i>	<b>Linear Elastic</b>
<i>Elastic Modulus</i>	<b>1.05E7</b>
<i>Poisson's Ratio</i>	<b>0.33</b>
<i>Density</i>	<b>2.6E-4</b>
<b>Apply</b>	

<i>Action:</i>	<b>Create</b>
<i>Object:</i>	<b>Isotropic</b>
<i>Method:</i>	<b>Manual Input</b>
<i>Material Name</i>	<b>alum_2</b>
<b>Input Properties...</b>	
<i>Constitutive Model:</i>	<b>Linear Elastic</b>
<i>Elastic Modulus</i>	<b>1.18E7</b>
<i>Poisson's Ratio</i>	<b>0.33</b>
<i>Density</i>	<b>2.4E-4</b>
<b>Apply</b>	

## Create Fields

8. Define fields that represent the varying thickness and temperature distribution. Use Table 14-1 to define the fields.

### ◆ Fields

<i>Action:</i>	<b>Create</b>
<i>Object:</i>	<b>Spatial</b>
<i>Method:</i>	<b>PCL Function</b>
<i>Field Name</i>	<b>thickness</b>
<i>Scalar Function</i>	<b>1.5-'Y/160</b>
<b>Apply</b>	

<i>Action:</i>	<b>Create</b>
<i>Object:</i>	<b>Spatial</b>
<i>Method:</i>	<b>PCL Function</b>
<i>Field Name</i>	<b>temperature</b>
<i>Scalar Function</i>	<b>200.-(150./160.)*'X</b>
<b>Apply</b>	

9. Create the element properties which include the material definitions and the varying thickness. Use the names **prop\_1** and **prop\_2** for the element property names.

Click on the **Properties** radio button in the *Main Form*. Using the information on Table 14-1 create element properties **prop\_1** and **prop\_2** for the top (cylindrical) and bottom (tapered) portions of the fairing respectively. Apply the element properties to the Quad elements. Use the **thickness** field you defined earlier to represent the varying shell thickness and materials **alum\_1** and **alum\_2** for the top and bottom portions of the model respectively.

### ◆ Properties

<i>Action:</i>	<b>Create</b>
<i>Dimension:</i>	<b>2D</b>
<i>Type:</i>	<b>Shell</b>
<i>Property Set Name</i>	<b>prop_1</b>

## Create Element Properties

*Options:*

Homogeneous

Standard Formulation

**Input Properties...**

*Material Name*

m:alum\_1

*Thickness*

f:thickness


**OK**

*Select Members*

Select the Top Elements of the Model. See figure below.

**Add**

**Apply**



*Action:*

**Create**

<i>Dimension:</i>	<input type="text" value="2D"/>
<i>Type:</i>	<input type="text" value="Shell"/>
<i>Property Set Name</i>	<input type="text" value="prop_2"/>
<i>Options:</i>	<input type="text" value="Homogeneous"/>
	<input type="text" value="Standard Formulation"/>

**Input Properties...**

<i>Material Name</i>	<input type="text" value="m:alum_2"/>
<i>Thickness</i>	<input type="text" value="f:thickness"/>

*Select Members*

Select the Bottom Elements of the Model. See figure on previous page.

- Define the model's varying temperature distribution. Use the name **temp** for the temperature set name.

**Create Temperature Boundary Conditions**

◆ **Load/BCs**

<i>Action:</i>	<input type="text" value="Create"/>
<i>Object:</i>	<input type="text" value="Temperature"/>
<i>Type:</i>	<input type="text" value="Nodal"/>
<i>New Set Name</i>	<input type="text" value="temp"/>

**Input Data...**

<i>Temperature</i>	<input type="text" value="f:temperature"/>
--------------------	--

**Select Application Region...**

*Geometry Filter*

*Select Nodes*

◆ **FEM**

Select All Nodes

Apply

Turn off the temperature labels

**Display/Load/BC/El. Props...**

**Loads/BCs**

**Temperature**

Apply

Cancel

11. Use Lists and Groups to filter then group the quad elements that have the following attributes:

Material:alum\_1 (MATRL.1 if you imported the model)

Thickness:> 0.98

Temperature: > 230.0

Add to *List A* the elements which have the alum\_1 (MATRL.1) material as one of their attributes.

**Create Lists**

**Tools/List/Create...**

*Model:*

FEM

*Object:*

Element

*Method:*

Attribute

*Attribute*

Material

*Existing Materials*

alum\_1

*Target List*

◆ A

Apply

Next, you will define *List B* to include only the Quad elements that have a *thickness greater than 0.98*.

◆ **Properties**

*Action:*

Show

*Existing Properties*


Thickness

*Display Method***Scalar Plot***Select Groups***FEM****Apply****Tools/List/Create...***Model:***FEM***Object:***Element***Method:***Attribute***Attribute***Fringe Value***Fringe Tools:***default\_Fringe***F*  **0.98***Target List*◆ **B****Apply****Intersect  
Lists**

Next, you will intersect Lists A and B and replace the contents of List A with the elements found in the intersection.

**Tools/List/Boolean...**

On the form that appears click on the intersect icon. The form should appear as follows:



To transfer the contents of List C to List A, click on the **Replace A** button in the *Boolean List* form.

List A currently satisfies the first two of our three conditions: Quad elements associated with material alum\_1 (*MATRL.1*) and having thickness > 0.98.

Now you will perform a final classification of the elements. You will isolate those elements that satisfy the third condition of applied temperature load > 230.0.

◆ **Load/BCs**

Action:

**Plot Contours**

Object:

**Temperature**

If you have imported the model from the neutral file, you need to switch the current load case to Load\_Case.1 to be able to select the temperature boundary condition.

Existing Sets

**temp (TEMPN.1.1)**

Select Data Variable

**Temperature**

Select Groups

**FEM**

**Apply**

**Tools/List/Create...**

Model:

**FEM**

Object:

**Element**

Method:

**Attribute**

Attribute

**Fringe Value**

Fringe Tools:

**default\_Fringe**

F

**230.0**

Target List

◆ **B**

Click on the **Clear** button in the *List B* form.


**Apply**

## Add List to Group

In the last portion of this step, you will intersect Lists A and B again to create List C. This will provide you with a list of elements that satisfy all 3 of the conditions. You will then put the contents of List C into the **common\_quads** group.

### Tools/List/Boolean...

Click on the *intersect* icon.



**Add To Group...**

*Group Name*

**common\_quads**

**Apply**

**Cancel**

Finally click on **Group** in the *Main Form*.


### Group/Post...

*Select Groups to Post*

**common\_quads**

**Apply**

In the *Load/Boundary Conditions* form re-render the temperature contours and Your model should appear as follows:



On the *Load/Boundary Conditions* form, click on the **Reset Graphics** button.

12. Create two groups by properties containing **prop\_1** and **prop\_2** respectively. In this step, you will be introduced to Group display mode concept. You will practice how to change the display attributes of a group of entities that represents a collection of different entity types (i.e. quad and bar elements). A major usage of this feature is demonstrated through displaying the same set of entities placed in two different groups in different render styles.

**Group  
Display  
Method**

**Group/Create...**

*New Group Name*

**prop1\_group**

*Group Contents:*

**Add Entity Selection**

**Apply**

Now to add the contents to the group you must create a list.

**Tools/List/Create...**

*Model:*

**FEM**

<i>Object:</i>	<input type="text" value="Element"/>
<i>Method:</i>	<input type="text" value="Attribute"/>
<i>Attribute</i>	<input type="text" value="Property Set"/>
<i>Existing Property Sets</i>	<input type="text" value="prop_1"/>
<input type="button" value="Apply"/>	

Next on the **List A** form select:

<input type="button" value="Add To Group..."/>	
<i>Group Name</i>	<input type="text" value="prop1_group"/>
<input type="button" value="Apply"/>	
<input type="button" value="Cancel"/>	

Repeat this process. Label the next group **prop2\_group** and select **prop\_2** from the *Existing Property Set*. Be sure to clear **List A** before you select **Apply** on the *List Create* form.

Change the view to **Isometric View 1**.



Now render each group with different render styles.

### Display/Entity Color/Label/Render...


<i>Entity Coloring and Labeling</i>	◆ <b>Group</b>
<i>Target Group</i>	<input type="text" value="prop1_group"/>
<i>Render Style</i>	<input type="text" value="Hidden Line"/>
<input type="button" value="Apply"/>	

Now that MSC.Patran is in group display mode, you can modify each group's display properties individually.

<i>Target Group</i>	<input type="text" value="prop2_group"/>
<i>Render Style</i>	<input type="text" value="Wireframe"/>
<i>Shade Color:</i>	<input type="text" value="Yellow"/>
<input type="button" value="Apply"/>	

Display each group separately using **Group/Post...** Note how the same set of entities can be displayed in different render styles. This feature proves to be extremely useful in the results post-processing. An example would be to display different results on the same set of finite elements, such as stress and temperature.

This figure shows both groups posted at once.



**File/Quit...**

