


WORKSHOP 5

Thermal Analysis using Imported CAD Geometry



Objective:

- In this exercise you will complete a thermal analysis of a model created from imported CAD geometry.



Model Description:

In this exercise analyze an oven lid clamp. The clamp geometry (in centimeters) will be imported as ProEngineer geometry; from it, create a **B-rep** solid. Use the Auto **TetMesh Mesher** to mesh the solid. Apply boundary conditions, complete the analysis and review the results.

This stainless steel (MID 364) clamp is used to clamp the perimeter flange on a pressurized processing oven lid. The oven lid surface can reach 300°C for several days. The lid is insulated; the insulation is sometimes pierced by the clamp edge. The clamp mounting boss is fastened with two bolts and thermal grease (total contact $h = 0.01 \text{ w/}^\circ\text{C-cm}^2$) to a room temperature (20°C) water cooled sink.

Determine both that the bracket mounting boss will remain at or below 50°C to ensure safe handling during disassembly and that the spring tab knee and boss transition areas remain at or below 150°C to prevent loss of clamping force due to creep.

This exercise will introduce a different format for guiding data entry, keystrokes, and mouse operations. Though all actions and entries required to accomplish a given step are provided some additional synthesis may be required by the user since exact images of the entry forms are not provided.

Exercise Overview:

- Open a new database named **exercise_05.db**.
- Import Pro/ENGINEER primitive geometry from a file named oventab.geo.
- Create a **B-rep** solid from these surfaces and delete the original surfaces in the process.
- Mesh the solid with the **TetMesh Mesher** using **Tet4** elements, a *global edge length* of **2.5**.
- Define an element property over all the solid elements using a material name of **364**.
- Create a boundary sink node **999** below the mounting boss and not associated with geometry.
- Change the view for application of boundary conditions
- Apply a 20°C fixed temperature to the sink node.
- Apply a fixed temperature of 300°C to the edge of the solid in contact with the lid.

- Apply a convection boundary condition of $0.01 \text{ w/}^\circ\text{C-cm}^2$ to the underside of the mounting boss.
- Select the **mpidcgs.bin** file in the P/Thermal Translation Parameters form in order to select the correct material property units.
- Run the analysis and read the results into the database.
- Fringe plot the temperature results and evaluate them against the requirements.
- **Quit** MSC.Patran.

Exercise Procedure:

Open a new database

1. Open a new database named **exercise_05.db**.

Within your window environment change directories to a convenient working directory. Run MSC.Patran by typing **p3** in your xterm window.

Next, select **File** from the *Menu Bar* and select **New ...** from the drop-down menu. Assign the name `exercise_05.db` to the new database by clicking in the *New Database Name* box and entering **exercise_05** (.db will automatically be appended).

Select **OK** to create the new database.

File	
New...	
New Database Name	exercise_05
OK	

MSC.Patran will open a Viewport and change various *Control Panel* selections from a ghosted appearance to a bold format. When the New Model Preferences form appears on your screen, set the *Tolerance* to **Default**, and the *Analysis Code* to **MSC/THERMAL**. Select **OK** to close the New Model Preferences form.

Tolerance	◆ Default
Analysis Code	MSC/THERMAL
OK	

- Import Pro/ENGINEER primitive geometry from a file named **oventab.geo**.


Select **File** from the *Menu Bar* and select **Import...** from the drop-down menu. Change the *Object*, *Source*, and *File Type* list boxes as shown below. It may be necessary to select a path and use the *Filter* button to locate the **oventab.geo** file which should be contained in your home directory.

File	
Import...	
Object	Model
Source	Pro/ENGINEER
File Type	Primitive Geometry
Pro/ENGINEER Files	oventab.geo
Apply	


The model geometry will be imported. A Pro/ENGINEER Model Import Summary form will provide statistics on the entity type and quantity imported. Click **OK** to close this form.

OK

The display should appear as shown below.




Select **Viewing** from the *Menu Bar* or use the Tool Bar *Iso 1 View* con to change to an isometric_view.



Or, use the Tool Bar *Iso 1 View* Icon.



The model should appear as shown below.



3. Create a B-rep solid from these surfaces and delete the original surfaces in the process.

Create a B-rep solid

Select the **Geometry Applications radio button**. Create a B-rep solid using the following *Action*, *Object*, and *Method*.

Geometry
 Create/Solid/B-rep
 Delete Original Surfaces
 Auto Execute

Surface List

<drag a rectangle around all surfaces>

A message window will request confirmation of deletion. Select **Yes**.

B-rep solid 1 is displayed as white in the viewport.

4. Mesh the solid with the **TetMesh Mesher** using **Tet4** elements, a *global edge length* of **2.5**.

TetMesh the B-rep solid

Select the **Finite Elements Applications radio button**. Set the *Action*, *Object*, and *Type* to **Create/Mesh/Solid**. The Isomesh Mesher is used on regular parametric solids. In order to mesh this B-rep solid use the **TetMesh Mesher**. Use the default **Tet4** topology and adjust the *Global Edge Length* and **TetMesh Parameters** to reduce the mesh resolution for this analysis.

Finite Elements
 Create/Mesh/Solid

Global Edge Length

2.5


Mesher

TetMesh

Input List

<select Solid 1>

Your model should appear as shown below.



Apply element properties to the elements

- Define an element property over all the solid elements using a material MID of **364**.

Select the **Properties Applications** radio button. Set the *Action*, *Dimension*, and *Type* to **Create/3D/Thermal 3D Solid**. In the Input Properties form enter an MID of **364** for the *Material Name* and select **Solid 1** as the *Select Member* region.

◆ Properties	
Create/3D/Thermal 3D Solid	
Property Set Name	Stainless_steel
Input Properties...	
Material Name	364
OK	
Select Members	<select Solid 1>
Add	
Apply	

6. Create a boundary sink node 999 below the mounting boss and not associated with geometry.

Create a boundary sink node

Select the **Finite Elements Applications** radio button. Create a boundary node which is not associated with geometry. The node is numbered **999**. Locate the node at **[0 -5 0]** centered below the mounting boss.

◆ Finite Elements

Create/Node/Edit

Node ID List

Associate with Geometry

Node Location List

Apply

7. Increase node display size and change the view to a Y-Z, **side_view**. Rotate the view to show the bottom surface of the mounting boss.

Increase node size and change to a Y-Z view

Increase the display size of nodes to facilitate the application of boundary condition. Use either **Display/Finite Elements...** or the associated Tool Bar icon to change the node size.

Display

Finite Elements...

Node Size (use slider bar)

Apply

Cancel

Select **Viewing** from the *Menu Bar* to change to a **side_view** of the model. Alternately, this step can be completed using the Tool Bar *Right Side View* icon.

Viewing

Named View Options...

Select Named View

Close

Using **Viewing/Transformations...** from the drop down menu to change the view point by tilting the 15° around the **-Z** axis to show the bottom surface of the mounting boss.

Viewing

Transformations...

Options...

Rotation increment (deg)

15 <use slider bar>


OK

<select this icon once for a 15° -Z rotation>



OK

The model should appear as shown below. Note location of Node 999.



8. Fix the boundary node temperatures at 20.0°C.

Begin applying boundary conditions. Select the **Loads/BCs Applications** radio button. Create a fixed 20.0°C nodal boundary named **Sink**.

Fix nodal boundary temperature

◆ **Loads/BCs**

Create/Temperature/Nodal

Option:

New Set Name

Input Data...

In the Input Data form define the fixed temperature.

Fixed Temperature

OK

Select Application Region...

In the Select Applications Region form pick node **999**.

◆ **FEM**

Select Nodes

Add

OK

Apply

In order to facilitate applying the next two boundary conditions change the display. Select **Display** then **Entity Color/Label/Render ...** Change *Render Style* to **Shaded/Flat** or use the Tool Bar *Smooth Shaded* icon to affect the change.

Display


Entity Color/Label/Render...

Render Style

Apply

Cancel

The display should appear as shown below. The lower contact edge of the spring tab, and the bottom of the mounting boss should now be visible.



Apply the fixed edge temperature. Enter a *New Set Name* **Edge** with a fixed temperature of **300.0°C** applied to lower edge of the spring tab.

New Set Name

Edge

Input Data...

Fixed Temperature

300.0

OK

Select Application Region...

◆ **Geometry**

Select Geometry Entities



<Choose *Select a Curve* icon, shown, from the *Select Menu*>

<select lower spring tab linear edge, Solid 1.15.3.>

Add

OK

Apply

The display should highlight each node and append the fixed temperature. On some displays the symbol and value may be difficult to discern.

9. Apply contact heat transfer coefficient.

Create the contact heat transfer coefficient boundary conditions with the **Template, Convection** option and the heat transfer coefficient provided, $0.01 \text{ w/}^\circ\text{C-cm}^2$. Name the set **contact** and apply the boundary condition to the surface on the bottom of the mounting boss.

**Apply
contact heat
transfer
coefficient**

◆ **Loads/BCs**

Create/Convection/Element Uniform

Option:	Template, Convection
New Set Name	contact
Target Element Type	3D

Input Data...

In the Input Data form provide the heat transfer coefficient and fluid node. Leave the *Template ID* field blank.

Convection Coefficient	0.01
Fluid Node ID	<select Node 999>

OK

Select Application Region...

In the Select Applications Region form select the bottom face of the mounting boss. When selecting the surface the surface chosen will be highlighted. If the incorrect surface is selected simply reselect closer to the centroidal location of the bottom mounting boss surface. The centroid is located between the mounting holes and centered on the width of the surface.

◆ **Geometry**


Select Solid Faces **<select the bottom surface of the mounting boss, Solid 1.1>**

Add

OK

Apply

With boundary conditions applied the model should appear as shown below.



10. Prepare and submit the model for analysis.

Prepare and run analysis

Reset the model to an **isometric_view**. Select **Viewing** from the *Menu Bar* to change to a **isometric_view** of the model. Alternately, this step can be completed using the Tool Bar *Iso 1 View* icon.

Viewing

Named View Options...

Select Named View

isometric_view

Close

Reset the graphics using the *Reset Graphics* icon.



Reduce node size using the *Node Size* icon.



Select the **Analysis Applications radio button** to prepare the analysis. There are five parameter forms. Change the **Translation Parameters...** as shown below. The analysis will be submitted by selecting **Apply** in the Analysis form.

◆ Analysis

Analyze/Full Model/Full Run

Translation Parameters...

File to Extract Undefined Materials: 4, mpidcgs.bin (CGS Units)

OK

Solution Parameters...

Calculation Temperature Scale ◆ Celsius

OK

Output Requests...

Units Scale for Output Temperatures ◆ Celsius

OK

Apply

11. Read results file and plot results.

From within MSC.Patran the only indication that the analysis has successfully finished is the existence of an **nrX.nrf.01** results file in a subdirectory one level below your working directory.

Recall that p3 was initiated from a working directory which contained the exercise_05.db database file. The analysis, initiated from within MSC.Patran, created a new subdirectory with the same name as the *Job Name*; it should be named **exercise_05/**. By using **Read Result** in the Analysis form and **Selecting Results File...** you can filter down to the *Job Name* subdirectory and check for the existence of the results file.

Read and plot results

◆ Analysis

Read Results/Result Entities

Select Results File...

Directories <path>/exercise_05

Filter

Available Files	<input type="text" value="nr0.nrf.01"/>
<input type="button" value="OK"/>	
<input type="button" value="Select Rslt Template File..."/>	
Files	<input type="text" value="pthermal_1_nodal.res_tmpl"/>
<input type="button" value="OK"/>	
<input type="button" value="Apply"/>	

To plot the results to posted FEM use the **Results Application radio button**.

<input type="button" value="◆ Results"/>	
<input type="button" value="Create/Quick Plot"/>	
Select Result Cases	<input type="text" value="TIME: 0.0000000000D+00 S..."/>
Select Fringe Result	<input type="text" value="Temperature,"/>

Select the *Fringe Attributes* icon.



Display:	<input type="text" value="Element Edges"/>
<input type="button" value="Label Style..."/>	
Label Format:	<input type="text" value="Fixed"/>
Significant figures	<input type="text" value="4 <use slider bar>"/>
<input type="button" value="OK"/>	
<input type="button" value="Apply"/>	

The model should now appear as shown on the front panel of this exercise.

What is the maximum reported temperature on the mounting boss? Is it at or below the required maximum of 50°C?

Do the spring tab knee and mounting boss transition temperatures meet the requirement of 150°C?

12. Quit MSC.Patran

To stop MSC.Patran select **F**ile on the *Menu Bar* and select **Q**uit from the drop-down menu.

**Quit
MSC.Patran**